

SAMPLING PROCEDURES

After purchasing the oil analysis on our shop, pick up at Oleobi containers, collect at our headquarters containers suitable for the type of analysis to be performed (the flasks are included in the cost of service)
Identify samples by writing machine name and date, send the samples together with the data necessary for their identification.

When to make the sampling

- IN MOTION:** if possible, while the machine is working
- WHILE HOT:** even if the machine is not working, sample the oil within 30 minutes from the shut-down, at the working temperature (max. 80 ° C)
- NOT:** after oil changes, or after significant oil refilling

How to make the sampling

- STANDARD PROCEDURE:** standardize the sampling procedures to perform repeatable samples
- BEFORE THE FILTERS:** sample preferably before of the filtering systems
- DYNAMIC SAMPLING:** if possible, sample from lines near curves, where the flow is more turbulent
- STATIC SAMPLING:** from tank or crankcase, to mid-height

SEND YOUR SAMPLES TO:

OLEOBI S.r.l Via Don G. Minzoni 28, 40057 Cadriano, Granarolo dell'Emilia (Bo)

At the end of the analysis you will receive a complete report in PDF format by email.

Attention analysis will be sent to the email contact used during registration